BOSE®

Owner's Guide

Guía de usario

Notice d'utilisation

SoundDock®10

digital music system

SAFETY INFORMATION

Please read this owner's guide

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy its advanced features. Please save this owner's guide for future reference.

WARNINGS:

- *To reduce the risk of fire or electrical shock, do not expose the product to rain or moisture.*
- *To prevent electric shock, match the wide blade of the line cord plug to the wide slot of the AC (mains) receptacle. Insert fully.*
- *Do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the apparatus. As with any electronic product, use care not to spill liquids into any part of the system. Liquids can cause a failure and/or a fire hazard.*
- *Do not place any naked flame sources, such as lighted candles, on or near the apparatus.*
- *Keep the remote control battery away from children. It may cause a fire or chemical burn if mishandled. Do not recharge, disassemble, heat above 100°C (212°F), or incinerate. Dispose of used batteries promptly. Replace only with a battery of the correct type and model number.*
- *Danger of explosion if battery is incorrectly replaced. Replace only with Duracell, Eveready, Energizer, Maxell, Toshiba, or Shun Wo CR2032 or DL2032 3-volt lithium battery.*
- *Contains small parts that may be a choking hazard. Not suitable for children under age 3.*
- **Please dispose of used batteries properly,** following any local regulations. Do not incinerate.

CE This product conforms to the EMC Directive 2004/108/EC and to the Low Voltage Directive 2006/95/EC. The complete Declarations of Conformity can be found at www.Bose.com/static/compliance/index.html.

CAUTIONS:


CAUTION
RISK OF ELECTRICAL SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED PERSONNEL.


AVIS
RISQUE DE CHOC ÉLECTRIQUE
NE PAS OUVRIR
ATTENTION : POUR RÉDUIRE LE RISQUE DE DÉCHARGE
ÉLECTRIQUE, NE RETIREZ PAS LE COUVERCLE (OU
L'ARRIÈRE). IL NE SE TROUVE À L'INTÉRIEUR AUCUNE
PIÈCE POUVANT ÊTRE RÉPARÉE PAR L'USAGER.
S'ADRESSER À UN RÉPARATEUR COMPÉTENT.

The lightning flash with arrowhead symbol within an equilateral triangle alerts the user to the presence of uninsulated dangerous voltage within the system enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle alerts the user to the presence of important operating and maintenance instructions in this owner's guide.

Notes:

- *The product label is located on the back of the product.*
- *Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.*
- *This product must be used indoors. It is neither designed nor tested for use outdoors, in recreation vehicles, or on boats.*
- *Make no modifications to the system or accessories. Unauthorized alterations may compromise safety, regulatory compliance, and system performance.*

Class B emissions

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations (Canada only).

If applicable, the radio communication device incorporated into this apparatus meets all requirements of the Industry Canada standard RSS-310 (Canada only).

English

IMPORTANT SAFETY INSTRUCTIONS

1. **Read these instructions –** for all components before using this product.
2. **Keep these instructions –** for future reference.
3. **Heed all warnings –** on the product and in the owner's guide.
4. **Follow all instructions.**
5. **Do not use this apparatus near water or moisture –** Do not use this product near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, or anywhere else that water is present.
6. **Clean only with a dry cloth –** and as directed by Bose Corporation. Unplug this product from the wall outlet before cleaning.
7. **Do not block any ventilation openings. Install in accordance with the manufacturer's instructions –** To ensure reliable operation of the product and to protect it from overheating, put the product in a position and location that will not interfere with its proper ventilation. For example, do not place the product on a bed, sofa, or similar surface that may block the ventilation openings. Do not put it in a built-in system, such as a bookcase or a cabinet that may keep air from flowing through its ventilation openings.
8. **Do not install near any heat sources, such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.**
9. **Only use attachments/accessories specified by the manufacturer.**
10. **Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.**
11. **Unplug this apparatus during lightning storms or when unused for long periods of time –** to prevent damage to this product.
12. **Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way: such as power supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped –** Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Bose to be referred to an authorized service center near you.
13. **To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.**
14. **Do not let objects or liquids enter the product –** as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock.
15. **See product enclosure for safety related markings.**
16. **Use proper power sources –** Plug the product into a proper power source, as described in the operating instructions or as marked on the product.

Information about products that generate electrical noise

U.S.A. only

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes to this device not expressly approved by Bose Corporation may void the user's authority to operate this device.

Canada

This Class B digital apparatus complies with the Canadian ICES-003 Class B specification.

For your records

Serial number: _____

Purchase date: _____

Dealer name: _____

Dealer phone: _____

Please keep your sales receipt with this owner's guide.

SoundDock and the distinctive design of the SoundDock 10 system are registered trademarks of Bose Corporation in the U.S. and other countries. iPod is a trademark of Apple Inc., registered in the U.S. and other countries. All other marks are registered trademarks and trademarks of Bose Corporation.

"Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license. Other trademarks and trade names are those of their respective owners.

English

THE SOUNDDOCK® 10 DIGITAL MUSIC SYSTEM

Introduction

Thank you for purchasing the SoundDock 10 digital music system. Offering a high-quality, room-filling sound, the SoundDock 10 digital music system can easily serve as the primary digital music system in your home.

Outstanding features:

- Proprietary acoustic design delivers full, rich sound
- Remote controls basic system functions including source selection
- Auxiliary input allows use with other audio devices
- Works with most iPod models
- Charges your device while it is docked
- Provides video output connection for a TV or monitor
- Available *Bluetooth*® dock accessory

Unpacking

Check the carton for all the parts shown.

Save the carton and packing materials, which provide the safest way to transport this product.

If any part of the product appears to be damaged, do not attempt to use it. Contact your authorized Bose dealer immediately or call Bose Customer Service. Refer to the address list enclosed in the carton for contact information.



☐ **SoundDock 10 digital music system**

☐ **Remote control**



☐ **AC power cord**

WARNING: *To avoid danger of suffocation, keep plastic bags out of the reach of children.*

Now is a good time to find the serial number on the back of your SoundDock 10 system and record it on the previous page.

Setting up your system

1. Place your SoundDock 10 digital music system on a flat, stable surface.
2. Plug the small end of the AC power cord into the AC power connector on the back of the unit.
3. Plug the other end into a live AC (mains) outlet. After you hear two short tones from your SoundDock 10 system, it is ready to use.



CAUTION: *Do not cover the ventilation openings of the product. The slots on the top provide ventilation for the built-in electronic circuitry and shall not be blocked.*

Note: *When handling the SoundDock 10 system, the front structure containing the iPod dock may feel loose. This is normal. This part of the system is intentionally designed to prevent speaker vibration from interferring with the operation of your iPod.*

System on/off control

You can turn on your SoundDock 10 system in any of the following three ways:

- Dock a device.
- Press any key except OFF on the Bose® remote.
- Press any key on the docked device.

To turn off the SoundDock 10 system, do either one of the following:

- Press OFF on the SoundDock 10 remote.
- Remove the docked device.

Listening to a docked device

1. Insert your iPod into the dock. The dock indicator glows on the front panel.



2. Use the Bose® remote to control system functions.

Note: *Your SoundDock® 10 digital music system charges your iPod whenever it is docked.*

Note: *Your SoundDock 10 digital music system comes with a universal dock adapter that can accommodate most iPod models. If you prefer to use the adapter that came with your iPod, see "Changing the dock adapter" on page 6.*



Dock
- *Press* to select the docked device.

Off
- *Press* to turn off the system.

Play/Pause
- *Press* to play or pause the current track on the docked device.

Volume +/–
- *Press* to increase (+) or decrease (–) the volume.
- *Press and hold* for faster adjustment.

Playlist select
- *Press* to select the next (☰▲) or previous (☰▼) playlist.

Skip forward
- *Press once* to skip to the next track.
- *Press and hold* to quickly scan forward through a track.

Skip backward
- *Press once* to skip to the beginning of the current track.
- *Press twice* to skip to the beginning of the previous track.
- *Press and hold* to quickly scan backward through a track.

Listening to other devices

You can connect the audio output of a PC, CD player, TV, MP3 player, or other type of audio device to the **AUX IN** connector. The **AUX IN** connector accepts a 3.5mm stereo cable plug.

1. Using the appropriate stereo cable, connect your audio device to the **AUX IN** connector.



Note: *A device must be plugged into the AUX IN connector in order to select the AUX source.*

2. Press AUX on the Bose® remote. The **AUX IN** indicator glows on the front panel.



3. Turn on the audio device and start playing music.

4. Set the volume of the device to near maximum.

Note: *The SoundDock 10 system is designed to provide the best audio performance without any additional audio effects. Make sure all audio effects are turned off in the connected device.*

5. Use the Bose® remote to increase or decrease the system volume.



Off
- *Press* to turn off the system.

AUX
- *Press* to select the AUX IN source.

Volume +/–
- *Press* to increase (+) or decrease (–) the volume.
- *Press and hold* for faster adjustment.

Notes:
- *The Bose remote will not control devices connected to AUX IN.*
- *A docked iPod will continue charging while you listen to a device connected to AUX IN.*

Using the video output

When playing a docked iPod with video capability, the VIDEO OUT connector provides a composite video output signal that can be viewed on a TV or computer monitor.

To view this video output on your TV or monitor, connect the VIDEO OUT to a video input using a standard composite video cable. Be sure to select the correct video input on your TV.



Changing the dock adapter

The SoundDock 10 digital music system comes with a pre-installed universal dock adapter, which accommodates most iPod models.

If you prefer to use the dock adapter included with your iPod:

1. Make sure the power cord is disconnected.
2. Lift up the back edge of the adapter and remove it from the dock.

   You may need to insert a thin, non-metallic utensil into the slot to provide the required leverage to lift the back edge.



Care and maintenance

Periodic maintaining may include cleaning your product and replacing the remote control batteries.

Cleaning

To clean the exterior surface of your product, you can wipe it using a soft, dry cloth. You can also lightly vacuum the grille.

- Do not use solvents, chemicals, or sprays.
- Do not allow liquids to spill or objects to drop into any openings.

Replacing the remote control batteries

When the remote stops operating or its range seems reduced, it is time to change the remote battery.

1. Using a coin, turn the battery cover slightly counter-clockwise.



2. Remove the used battery and insert the new one (CR2032 or DL2032). Refer to page ii for battery information and safety instructions. Be sure the battery is flat side up, with the positive (+) symbol in view.



3. Reseat the cover and turn it clockwise until it locks into place.



Troubleshooting

The following troubleshooting table should help solve operating problems with your SoundDock 10 system. However, before using the table, do the following:

- Remove your iPod from the dock and check for obstructions on the dock connector and on your iPod. Then firmly reseat it in the dock.
- Make sure you have the latest software on your iPod.



Note: *If your iPod has four buttons above the touch wheel, it is not compatible with the SoundDock 10 system. You can listen to this model iPod when it is docked, but the SoundDock 10 system will not charge it.*

Problem	What to do
I do not hear any sound from the SoundDock 10 system.	• Make sure the power cord is properly connected on the back of the SoundDock 10 system and that the system is plugged into a live AC outlet. • Press the source button (dock or AUX) on the remote for the source you are using. • Press the Play/Pause button on the remote control. • Increase the system volume. • If listening to a device connected to AUX IN, increase the volume on the device. • Remove your iPod from the dock, wait 5 seconds, then reseat it. • Unplug the power cable for 1 minute, then plug it back in to reset the system.
My iPod is not charging.	• Make sure the power cord is properly connected on the back of the unit. • Make sure the system is plugged into a live AC outlet.
I cannot navigate the playlists on my iPod.	• Make sure that you have created playlists on your iPod.
My iPod does not respond to the remote control.	• Make sure there is a clear path between the remote and the system. • Using a clean, dry cloth, wipe the small lens on the front end of the remote. • Try the remote from a different location. You may be experiencing interference from bright room lights or sunlight. • Remove your iPod from the dock, wait 5 seconds, then reseat it. • Make sure the remote battery is installed correctly or replace it if it is old (refer to page 6).
My system does not respond to any controls.	• Unplug the power cable for 1 minute, then plug it back in to reset the system. • Contact Bose® Customer Service.

Customer service

For questions about the SoundDock 10 digital music system, contact your local Bose dealer. To contact Bose directly, see the address list included in the carton.

Limited warranty

Your SoundDock 10 digital music system is covered by a limited transferable warranty. Details of the limited warranty are provided on the product registration card that is included in the carton. Please refer to the card for instructions on how to register. Failure to register will not affect your limited warranty rights.

What you must do to obtain limited warranty service

Return product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Visit **http://global.Bose.com** or contact your local authorized Bose dealer to identify the location of the nearest authorized Bose® service facility.
2. Contact the authorized service facility for specific return and shipping instructions.
3. Label and ship the product, freight prepaid, to the address provided by the authorized service facility.
4. Place any necessary return authorization number prominently on the outside of the carton.

   Cartons not bearing a return authorization number, where required, will be refused.

Technical Information

Input power rating

U.S.A./Canada: 100-120V~ 50/60Hz, 150W

International: 220-240V~ 50/60Hz, 150W
100-240V~ 50/60Hz, 150W

Dimensions

8.7"H x 17.0"W x 9.6"D (22.1 cm x 43.2 cm x 24.4 cm)

Weight

18.5 lb (8.4 kg)

Made for iPod

BOSE®
Better sound through research®

©2008 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM314136 Rev.00

314136

Bose® Personal Audio Products

Productos de Audio Personal de Bose®

Produits Audio Personnel de Bose®

On the go. At work. At home.

En la calle. En el trabajo. En el hogar.

En déplaçement. Au travail. À la maison.

BOSE®

Better sound through research®

Computer MusicMonitor™

MusicMonitor™ altavoces para computadoras

Enceintes d'ordinateur MusicMonitor™

Our premium two-piece amplified system. Advanced Bose® technology delivers unexpected performance from our smallest two-piece speaker system.

Nuestro sistema de amplificación de dos piezas premium. Sistema de amplificación de dos piezas. La avanzada tecnología de Bose® brinda un rendimiento sorprendente desde nuestro sistema de altavoces de dos piezas más pequeño.

Notre système amplifié haut de gamme à deux enceintes. Notre plus petit ensemble à deux enceintes vous offre une performance insoupçonnée grâce à la technologie de pointe de Bose®

Companion® 5 multimedia speaker system

Companion® 5 sistema de altavoces multimedia

Enceintes multimédia Companion® 5

Our best-performing three-piece computer speaker system delivers lifelike sound that seems to surround you Designed for 5.1-encoded music, games and movies.

Nuestro mejor sistema de altavoces para computadoras compuesto de tres piezas brinda un sonido real sorprendente que parece envolverlo. Diseñado para sonido codificado en 5.1 de música, juegos y películas.

Notre ensemble à trois enceintes d'ordinateur le plus performant offre une sonorité naturelle qui semble vous entourer. Conçu pour la musique, les films, et les jeux codés en format 5.1.

Companion® 3 Series II multimedia speaker system

Companion® 3 Serie II sistema de altavoces multimedia

Enceintes multimédia Companion® 3 Série II

A vivid stereo sound experience right at your desktop, from two sleek speakers and a hideaway Acoustimass® module.

Una experiencia de sonido estéreo intenso en su escritorio, a través de dos elegantes altavoces y un módulo Acoustimass® oculto.

Vivez une expérience stéréophonique intense à même votre bureau grâce à deux enceintes profilées et un module Acoustimass® dissimulable.

Companion® 2 Series II multimedia speaker system
Companion® 2 Serie II sistema de altavoces multimedia
Enceintes multimédia Companion® 2 Série II

Two speakers that represent a significant upgrade in sound and style over your computer's original speakers.

Dos altavoces que representan una gran mejora en calidad de sonido y estilo respecto de los altavoces originales de su computadora.

Deux enceintes qui constituent une amélioration marquée de la qualité sonore et du style par rapport aux anciennes enceintes de votre ordinateur.

SoundDock® Series II digital music system
SoundDock® Serie II, sistema de música digital
Système musical numérique SoundDock® série II

Enjoy music from your iPod in rich, room-filling sound. Designed with Bose® technology for a unique combination of small size and powerful performance. An auxiliary input lets you easily connect other audio devices.

Disfrute la música de un iPod con un sonido rico que se dispersa por toda la habitación. Diseñado con tecnología Bose® brinda una combinación única de tamaño reducido y rendimiento de gran potencia. Además tiene una entrada auxiliar para conectar otros dispositivos de audio fácilmente.

Profitez de la musique de votre iPod avec une riche sonorité qui remplit toute la pièce. Conçu à partir des technologies Bose,® ce système offre une combinaison unique : un format compact allié à une grande performance. Une prise d'entrée auxiliaire vous permet de raccorder facilement d'autres appareils audio.

SoundDock® Portable digital music system
SoundDock® Portátil, sistema de música digital
Système musical numérique SoundDock® Portable

Delivers the same level of quality sound as the SoundDock Series II system, even unplugged. A rechargeable, lithium-ion battery provides hours of playtime, so you can take the system from room to room, or even outside. An auxiliary input lets you connect other audio devices.

Brinda el mismo nivel de sonido de calidad que el sistema SoundDock Serie II, también cuando está desenchufado. La batería recargable de ion de litio brinda horas de reproducción, así que el sistema se puede trasladar de una habitación a otra, o incluso al exterior. Además tiene una entrada auxiliar para conectar otros dispositivos de audio.

Ce système offre la même qualité sonore que le système SoundDock série II, même quand il n'est pas branché à une prise de courant. Une batterie rechargeable au lithium-ion procure des heures de musique, ce qui vous permet de transporter le système d'une pièce à l'autre, et même à l'extérieur. Une prise d'entrée auxiliaire permet de raccorder d'autres appareils audio.



QuietComfort® Acoustic Noise Cancelling® headphones

Auriculares/audífonos QuietComfort® Acoustic Noise Cancelling®

Casques QuietComfort® Acoustic Noise Cancelling®

An unmatched combination of noise reduction, audio performance and comfortable fit. Choose QC®2 headphones for an around-ear design or QC®3 headphones for an on-ear alternative.

Ofrecen una incomparable combinación de reducción del ruido, reproducción de audio y calce cómodo. Elija los auriculares/audífonos QC®2 con el diseño alrededor del oído o los auriculares/audífonos QC®3 diseño sobre el oído como alternativa.

Une combinaison inégalée de réduction du bruit, de qualité sonore et de confort. Optez pour le casque QC®2 pour une conception circum-auriculaire ou pour le casque QC®3 de conception supra-auriculaire.

Bose® in-ear headphones

Auriculares/audífonos Bose® *intra*

Casque Bose® *intra*

High-quality audio from an in-ear design. Engineered to rest gently in the outer bowl of your ear, they offer a comfortable fit not found in most conventional earbuds.

Audio de alta calidad en un cómodo diseño en el oído. Diseño que se apoya suavemente en el parte exterior del conducto auditivo. Brinda un calce cómodo que no se encuentra en los auriculares/audífonos convencionales.

Un son de haute qualité grâce à une conception intra-auriculaire. Cette conception permet aux écouteurs de reposer en douceur dans le creux de l'oreille et offre un confort inégalé par la plupart des écouteurs-boutons conventionnels.

Bose® on-ear headphones

Auriculares/audífonos Bose® *supra*

Casque Bose® *supra*

High-performance audio in a lightweight, on-ear design. Fold-flat earcups and a collapsible headband offer increased portability.

Audio de alto desempeño en un liviano diseño que se apoya sobre los oídos. Auriculares/audífonos y banda plegables que permiten transportarlos fácilmente.

Une qualité sonore supérieure grâce à une conception légère supra-auriculaire. Écouteurs repliables et serre-tête télescopique pour faciliter le transport.

Bose® around-ear headphones

Auriculares/audífonos Bose® *circum*

Casque Bose® *circum*

High-quality audio in an around-ear design. Delivers clarity and range you might not expect from headphones this lightweight and comfortable.

Audio de alta calidad en un cómodo diseño alrededor del oído. Ofrece una nitidez y amplitud de sonido que no se esperarían de auriculares/audífonos tan livianos y cómodos.

Un son de haute qualité grâce à une conception à porter circum-auriculaire. Offre une clarté et un spectre sonore inattendus d'un casque d'écoute étonnamment léger et confortable.

BOSE

OUR COMMITMENT TO YOU

We take great pride in designing each of our products with the goal of providing the highest accuracy musical performance possible in the price range of that product. We strive to reproduce the musical sounds as closely as possible to those of the original performance. And we strive to avoid flashy sounds such as those associated with accentuated bass and/or treble frequencies. While those sounds may be initially attractive to the novice, they are not real and are not enduring. In addition, we use only the highest quality parts and the latest assembly and quality control techniques to ensure the reliability and long life of our products.

Our reputation rests on our steadfast pursuit of this policy in sound systems for the home, the automobile, and businesses.

At Bose® we reinvest 100% of our earnings back into the company. This enables us to support research that continually gives rise to new technologies for improving sound reproduction.

When you purchase any product from Bose, we encourage you to compare it, as we do, to competitive products for musical accuracy. We believe that this process will enhance your appreciation of the product you select.

With best wishes from all of us at Bose for many years of enjoyable listening.

©2000 Bose Corporation 251001 AM Rev.04 JN00235

BOSE CORPORATION, THE MOUNTAIN, FRAMINGHAM, MA 01701-9168 U.S.A. TEL.: 508.879.7330 FAX: 508.766.7543 WWW.BOSE.COM

Bose Corporation

USA
Bose Corporation, The Mountain
Framingham, MA 01701-9168
1-800-367-4008 or 508-766-1900
Phone hours - ET (Eastern Time):
Weekdays 8:30 a.m. to 8 p.m.
Saturdays 9 a.m. to 3 p.m.
owners.bose.com

Canada
Bose Ltd., 1-35 East Beaver Creek Road
Richmond Hill, Ontario L4B 1B3
1-800-465-2673
Phone hours - ET (Eastern Time):
Weekdays 9 a.m. to 5 p.m.
www.bose.ca

Australia
Bose Pty Limited, Unit 3/2 Holker Street
Newington NSW 2127
TEL 612 8737 9999 FAX 612 8737 9924

Belgique/België
Bose N.V., Limesweg 2
B-3700 Tongeren
TEL 012-390800 FAX 012-390840

China
Bose Electronics (Shanghai) Ltd
2203-2305 22F, West Gate Tower
1038 West Nanjing Road
MeiLongzhen Plaza
Shanghai 200041
Peoples Republic of China
TEL 86-22-62713000 ext 162
FAX 86-21-62713008

Danmark
Bose A/S, Industrivej 7
2605 Brøndby
TEL 04343-7777 FAX 04343-7818

Deutschland
Bose GmbH, Max-Planck-Straße 36d
D-61381 Friedrichsdorf
TEL 06172-71040 FAX 06172-710419
www.bose.de

France
Bose S.A.S.
12 rue de Témara
78100 Saint Germain en Laye
TEL 01 30 61 63 63 FAX 01 30 61 63 88
www.bosefrance.fr

India
Bose Corporation India Private Limited
4th Floor,
Shriram Bhartiya Kala Kendra,
1 Copernicus Marg
New Delhi, India 100 001
TEL +91 11 2307 3825 / 3826 / 3827
FAX +91 11 2307 3823

Ireland
Bose GP
Castleblayney Road
Carrickmacross, Co Monaghan
TEL (042) 9671500 FAX (042) 9671501
www.bose.ie

Italia
Bose S.p.A., Via della Magliana 876
00148 Roma
TEL 06 60 292 292 FAX 06 60 292 119
www.bose.it

Japan
Bose K.K.
Shibuya YT Building
28-3 Maruyama-cho
Shibuya-ku, Tokyo 150-0044
TEL +81-3-5489-0955 FAX +81-3-5489-1041
www.bose.co.jp

Mexico
Bose de Mexico S. de R.L. de C.V.
Paseo de las Palmas # 405
Despacho 204
Lomas de Chapultepec
C.P. 11000, Mexico D.F., Mexico
TEL +52 (55) 52 02 35 45
TEL +52 (55) 52 02 41 95
FAX +52 (55) 52 02 37 28

Nederland
Bose B.V., Nijverheidstraat 8
1135 GE Edam
TEL 0299-390111 FAX 0299-390109
consumenteninfo@bose.com
www.bose.nl

Norge
Bose A/S, Lerkeveien 58
2209 Kongsvinger
TEL 62 82 15 60 FAX 62 82 15 69

Österreich
Bose Ges.m.b.H., Vienna Business Park
Wienerbergstrasse 7 (10.OG)
A-1100 Vienna
TEL 01-60404340 FAX 01-604043423
www.bose.at

Schweiz
Bose AG, Hauptstrasse 134
4450 Sissach
TEL 061-9757733 FAX 061-9757744
www.bose.ch

Sverige
Bose A/S, Johannefredsgatan 4
S-43153 Mölndal
TEL 031-878850 FAX 031-274891

United Kingdom
Bose Limited
1 Ambley Green
Gillingham Business Park
Gillingham, Kent ME8 ONJ
TEL 0870-741-4500 FAX 0870-741-4545
www.bose.co.uk

World Wide Web
www.bose.com
www.boseeurope.com
owners.bose.com

289347-001

BOSE®
Better sound through research®

©2006 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA
AM289347 Rev.03 CCM-040001

For more information about
these or other Bose® products:

Para obtener más información
sobre estos u otros productos de Bose®:

Pour obtenir de plus amples renseignements
sur ces produits ou sur d'autres produits
Bose®, communiquez avec nous :

1-800-485-4072

www.Bose.com/personalaudio

Outside U.S./Fuera de los Estados Unidos/
À l'extérieur des États-Unis :

http://global.Bose.com/pa

BOSE®

©2008 Bose Corporation.
iPod is a trademark of Apple Inc., registered in the U.S. and other countries. iPod es una marca comercial de Apple Inc., registrada en EE.UU. y otros países. iPod est une marque commerciale d'Apple Inc., et une marque déposée aux États-Unis et dans d'autres pays.

310403-001

C_006410 AM310403_02

BOSE®

Warranty information inside
Register your product now

Contiene información sobre la garantía
Registre su producto ahora

Renseignements sur la garantie à l'intérieur
Enregistrez votre produit dès maintenant

Registre su producto.* Conozca toda la gama de servicios que su garantía le ofrece.

Registrarse en línea es fácil y rápido.
Global.Bose.com/register

Enlace directo para registrarse:

www.register.Bose.eu *(Europa)*
www.Bose.com/register *(EE.UU., Puerto Rico e Islas Vírgenes de EE.UU.)*
www.Bose.com.au/warranty *(Australia)*
www.Bose.ca/register *(Canadá)*
www.Bose.co.nz/warranty *(Nueva Zelanda)*

Envíe cualquier correspondencia en relación con información de productos o los servicios de la Garantía limitada a la sede corporativa de la empresa en:

Registro del producto
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 EE.UU.

1-800-736-5076 (EE.UU.)
1-508-766-1000 (INTL) *Es posible que se apliquen cargos por la llamada. Tenga a mano el número de serie cuando realice la llamada.*

Los propietarios que vivan fuera de los Estados Unidos deben revisar la Guía del usuario o ir a Global.Bose.com para encontrar la dirección más cercana.

GARANTÍA LIMITADA

A quién cubre:
Esta garantía se extiende únicamente al comprador final original o a la persona que reciba el producto como regalo y no se extenderá a cualquier otra persona o beneficiario.

Qué se cubre/Por cuánto tiempo:
A menos que un período de garantía diferente se explicite en la Guía del usuario provista con su producto Bose®, por un período de 1 año (2 años en la UE.) [5 años para altavoces no eléctricos incorporados en el producto] a partir de la fecha de la compra minorista por parte del usuario final original, Bose garantiza que este producto, cuando se le entrega en su paquete original y en nueva condición, por parte de un revendedor autorizado por Bose y es utilizado en condiciones normales, no tiene defectos de fabricación, de materiales ni de producción.

Qué es lo que no se cubre:
Esta garantía no cubre defectos ocasionados por prácticas de uso o mantenimiento incorrectas o no razonables, el incumplimiento de las instrucciones de uso; accidentes; humedad excesiva; insectos; rayos; subidas de tensión; conexión a voltaje incorrecto; alteraciones o modificaciones no autorizadas del producto original; daños causados por embalaje o proceso de envío inapropiado; pérdida, daño o alteración de la información guardada; daños ocasionados por el uso con productos que no sean de Bose; productos que requieren de modificación o adaptación para permitir que se utilicen en cualquier país fuera del país para el que fueron diseñados, fabricados, aprobados y/o autorizados, o reparación de productos dañados por estas modificaciones; y productos adquiridos de vendedores no autorizados.

Qué haremos:
Durante el período de garantía repararemos o sustituiremos, a nuestra discreción, las partes defectuosas en un período razonable de tiempo y sin cargo utilizando repuestos nuevos o rehabilitada.

Qué es lo que no haremos:
Pagar cargos por envío, seguros o transporte del producto de usted a nosotros, tasas de importación o impuestos.

Qué debe hacer para obtener el servicio de la Garantía limitada:
Devuelva el producto con el comprobante de compra emitido por un vendedor autorizado de Bose, realizando los siguientes pasos:

1. Contáctese con la compañía Bose en su país/región (visite Global.Bose.com para obtener información de contacto en su país/región) a fin de obtener instrucciones específicas sobre devolución y envío;
2. Rotule y envíe el producto, con flete pago, a la dirección de la compañía Bose en su país; y
3. Coloque cualquier número de autorización para la devolución que sea necesario en forma visible y en la parte exterior del paquete. Los paquetes que no tengan un número de autorización de devolución, cuando sea necesario, serán rechazados.

Otras condiciones:
LAS DISPOSICIONES DE ESTA GARANTÍA LIMITADA REEMPLAZAN CUALQUIER OTRA GARANTÍA, YA SEA EXPRESA O IMPLÍCITA, ESCRITA U ORAL, INCLUYENDO CUALQUIER GARANTÍA DE COMERCIABILIDAD O ADECUACIÓN A UN FIN PARTICULAR. LA RESPONSABILIDAD MÁXIMA DE BOSE CORPORATION NO PUEDE EXCEDER EL PRECIO DE COMPRA REAL QUE USTED PAGÓ POR EL PRODUCTO. BAJO NINGUNA CIRCUNSTANCIA SERÁ BOSE RESPONSABLE POR LA PÉRDIDA, DAÑO O ALTERACIÓN DE INFORMACIÓN GUARDADA O POR DAÑOS ESPECIALES, INCIDENTALES, EN CONSECUENCIA O INDIRECTOS CUALQUIERA SEA LA CAUSA DE LOS MISMOS, INCLUYENDO SIN LIMITACIÓN, EL REEMPLAZO DE EQUIPOS Y PROPIEDADES Y CUALQUIER COSTO DE RECUPERACIÓN, PROGRAMACIÓN O REPRODUCCIÓN DE CUALQUIER PROGRAMA O INFORMACIÓN GUARDADA O UTILIZADA CON SU PRODUCTO BOSE. Esta garantía se anula en caso de que la etiqueta con el número de serie haya sido quitada o dañada.

Otros derechos legales:
Esta garantía limitada le otorga derechos legales específicos y es posible que también se le otorguen otros derechos que varían según los estados o países. Algunos lugares no permiten limitaciones en garantías implícitas o la exclusión o limitación por daños secundarios o resultantes, por lo que es posible que las limitaciones o exclusiones anteriores no se apliquen a usted.

**En caso de que no registre su producto no se verán afectados sus derechos de garantía limitada.*

Enregistrez votre produit.* Renseignez-vous sur la gamme complète de services offerts dans le cadre de notre garantie.

L'enregistrement en ligne est simple et rapide.
Global.Bose.com/register

Liens directs vers les sites d'enregistrement :

www.register.Bose.eu *(Europe)*
www.Bose.com/register *(États-Unis, Puerto Rico et Îles Vierges des États-Unis)*
www.Bose.com.au/warranty *(Australie)*
www.Bose.ca/register *(Canada)*
www.Bose.co.nz/warranty *(Nouvelle-Zélande)*

Pour toute correspondance relevant d'une demande de renseignements au sujet de nos produits ou de nos services de garantie limitée, veuillez nous écrire à notre siège social, à l'adresse suivante :

Enregistrement de produits
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 États-Unis

1-800-736-5076 (États-Unis)
1-508-766-1000 (international) *Des frais peuvent s'appliquer. Veuillez avoir en main votre numéro de série lors de l'appel.*

Si vous résidez hors des États-Unis, consultez le guide de l'utilisateur ou le Global.Bose.com pour obtenir l'adresse postale la plus proche.

GARANTIE LIMITÉE

Bénéficiaire :
La présente garantie est uniquement valable pour le premier acheteur ou la personne ayant reçu le produit en cadeau et ne peut en aucun cas être étendue ou transférée à une autre personne.

Objet et durée de la garantie :
À moins qu'une durée différente ne soit indiquée dans le guide de l'utilisateur fourni avec le produit, Bose® garantit pendant une période d'un an (deux ans dans l'UE) [cinq ans pour tout haut-parleur non amplifié intégré au produit], à partir de la date d'achat au détail par le premier acheteur, que le produit est libre de tout vice de matériaux et de fabrication lorsqu'il est livré à l'état neuf, dans son emballage d'origine et par un détaillant autorisé Bose, et qu'il est utilisé dans des conditions normales.

Exclusions :
La présente garantie ne couvre pas : les défauts ou dommages résultant d'une utilisation ou d'un entretien inapproprié ou incorrect, du non-respect des directives d'utilisation, d'un accident, d'une humidité excessive, de la présence d'insectes, de la foudre, d'une pointe de courant électrique, d'un raccordement à un courant électrique d'une tension incorrecte, d'une altération ou d'une modification du produit, de procédures d'emballage ou d'expédition inappropriées; la perte, l'altération ou la détérioration de données informatiques; les dommages causés par l'utilisation avec un produit d'une marque autre que Bose; les modifications ou adaptations effectuées au produit pour qu'il soit utilisable dans un pays autre que celui pour lequel il a été conçu, fabriqué, approuvé et/ou autorisé, de même que la réparation d'un produit endommagé par ces modifications; les produits achetés auprès d'un détaillant non agréé.

Notre engagement :
Au cours de la période de garantie, à notre seule discrétion, nous réparerons ou remplacerons toute pièce défectueuse dans un délai raisonnable, sans frais utilisant nouvel ou rénové les parties de remplacement.

Frais exclus :
La garantie ne couvre pas le paiement des frais d'expédition, d'assurance et de transport du produit vers notre adresse, ainsi que de toutes taxes et de tous droits d'importation ou autres.

Conditions de l'obtention des services de garantie limitée réparation :
Expédiez-nous le produit, accompagné de la preuve d'achat d'origine d'un détaillant Bose autorisé, en suivant les directives ci-dessous :

1. Communiquez avec l'entité Bose de votre pays ou région (consultez le site Global.Bose.com pour connaître les coordonnées de Bose dans votre pays ou région) pour obtenir les instructions de retour et d'expédition particulières;
2. Étiquetez et expédiez le produit, en port payé, à l'adresse fournie par l'entité Bose de votre pays ou région; et
3. Inscrivez de façon très visible sur l'extérieur de l'emballage tout numéro d'autorisation de retour nécessaire. Un envoi qui ne comporte pas de numéro d'autorisation de retour lorsque celui-ci est requis sera refusé.

Autres conditions :
LES CONDITIONS DE LA PRÉSNTE GARANTIE LIMITÉE REMPLACENT TOUTE AUTRE GARANTIE, EXPRESSE OU IMPLICITE, EXPRIMÉE PAR ÉCRIT OU ORALEMENT, Y COMPRIS TOUTE GARANTIE DE QUALITÉ MARCHANDE OU D'ADAPTATION À UN USAGE PARTICULIER. LA RESPONSABILITÉ MAXIMALE DE BOSE CORPORATION ÉQUIVAUT AU PRIX PAYÉ PAR LE CONSOMMATEUR À L'ACHAT DU PRODUIT. BOSE NE PEUT EN AUCUN CAS ÊTRE TENUE RESPONSABLE DE LA PERTE, DE L'ALTÉRATION OU DE LA DÉTÉRIOATION DE DONNÉES INFORMATIQUES, NI DE DOMMAGES PARTICULIERS, ACCESSOIRES OU INDIRECTS, QUELLE QU'EN SOIT LA CAUSE, Y COMPRIS, SANS RESTRICTION, LE REMPLACEMENT D'ÉQUIPEMENT ET DE BIENS ET TOUS FRAIS DE RÉCUPÉRATION, DE PROGRAMMATION OU DE REPRODUCTION DE TOUT PROGRAMME OU DE TOUTES DONNÉES ENREGISTRÉS DANS LE PRODUIT BOSE OU UTILISÉS AVEC CELUI-CI. La présente garantie est annulée si l'étiquette portant le numéro de série est retirée ou altérée.

Autres droits :
La présente garantie limitée vous confère des droits particuliers selon la loi; vous pouvez aussi bénéficier d'autres droits qui varient selon votre pays ou région de résidence. Certains territoires ne permettant pas la limitation des garanties implicites ou l'exclusion ou la limitation des dommages indirects ou accessoires, il est donc possible que les limites ou exclusions ci-dessus ne s'appliquent pas à vous.

**Le non-enregistrement du produit n'affecte aucunement vos droits en vertu de la garantie limitée.*

Register your product.* Learn about the full range of services your warranty provides.

Registering online is quick and easy!
Global.Bose.com/register

To link directly to registration:

www.register.Bose.eu *(Europe)*
www.Bose.com/register *(US, PR & USVI)*
www.Bose.com.au/warranty *(Australia)*
www.Bose.ca/register *(Canada)*
www.Bose.co.nz/warranty *(New Zealand)*

Send any correspondence regarding product information or Limited Warranty services to our corporate headquarters at:

Product Registration
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 USA

1-800-736-5076 (US)
1-508-766-1000 (INTL) *Charges may apply.*
Please have your serial number available when you call.

Owners living outside the United States should check the Owner's Guide or Global.Bose.com for the nearest mailing address.

LIMITED WARRANTY

Who is covered:
This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift, and shall not be extended to any other person or transferee.

What is covered/For how long:
Unless a different warranty period is stated in the Owner's Guide provided with your Bose® product, for a period of 1 year (2 years EU) [5 years for any non-powered speakers that may be incorporated into this product] from the date of retail purchase by the original end-use purchaser, Bose warrants that this product, when delivered to you in new condition, in original packaging, from a Bose authorized reseller and used in normal conditions, is free from any defects in manufacturing, materials and workmanship.

What is not covered:
This warranty does not cover defects resulting from improper or unreasonable use or maintenance; failure to follow operating instructions; accident; excess moisture; insects; lightning; power surges; connections to improper voltage supply; unauthorized alteration or modification of original condition; damages caused by inadequate packing or shipping procedures; loss of, damage to or corruption of stored data; damages caused by use with non-Bose products; product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications; and products purchased from unauthorized dealers.

What we will do:
During the warranty period, we will, at our sole option, repair or replace (using new or refurbished replacement parts) any defective parts within a reasonable period of time and free of charge.

What we will not do:
Pay shipping, insurance or transportation charges from you to us, or any import fees, duties and taxes.

What you must do to obtain Limited Warranty Service:
Return product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Contact the Bose organization in your country/region (visit Global.Bose.com for Bose contact information in your country/region) for specific return and shipping instructions;
2. Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country; and
3. Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number, where required, will be refused.

Other conditions:
THE PROVISIONS OF THIS LIMITED WARRANTY ARE IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESSED OR IMPLIED, WRITTEN OR ORAL, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. BOSE CORPORATION'S MAXIMUM LIABILITY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID BY YOU FOR THE PRODUCT. IN NO EVENT SHALL BOSE BE LIABLE FOR LOSS OF, DAMAGE TO OR CORRUPTION OF STORED DATA, OR FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR INDIRECT DAMAGES HOWSOEVER CAUSED INCLUDING WITHOUT LIMITATION THE REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, PROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH YOUR BOSE PRODUCT. This warranty is void if the label bearing the serial number has been removed or defaced.

Other legal rights:
This limited warranty gives you specific legal rights, and you also may have other rights that vary from state to state or country to country. Some places do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

**Failure to register your product will not affect your limited warranty rights.*